


**DP11 SERIES PNEUMATIC PICK HAMMER  
PART ILLUSTRATION  
WITH PART LIST**

**MCD-DP11VRS**



**7** THROTTLE VALVE SEAL  
1255029 (005005)

**8** THROTTLE VALVE STEM  
5580004 (169003)

**9** THROTTLE VALVE BALL  
2841013 (023014)

**10** SEAL  
1080050 (162020)

**11** ADAPTOR  
9017027 (901081)

**12** 3/4" BSPP FEMALE COUPLING  
2841048 (908201)

**13** AIR FEED PIPE SEAL  
5580011 (169008)

**14** INTERNAL CIRCLIP  
5580034 (169028)

**15** AIR DISTRIBUTOR  
5580008 (169027)

**16** AIR DISTRIBUTOR SEAL  
5580009 (169007)

**17** PISTON  
5580007 (169019)

**37** MUFFLER COMPLETE  
5580034 (169028)

**25** VALVE PIVOT PIN  
5580014 (169012)

**26** CYLINDER  
5580001 (169009)

**27** SNAP RING  
5580033 (169030)

**28** TOOL BUSHING  
5580020 (153002)

**34** CHUCK LOCATION BOLT  
5580022 (169023)

**35** CHUCK LOCATION NUT  
5580023 (169024)

**36** SPRING - PLUNGER  
0355017 (153018)

**1** CAP SCREW (4)  
5580028 (169026)

**2** THROTTLE LEVER  
5580010 (169002)

**3** LEVER PIN (2)  
5580003 (162032)

**4** HANDLE  
5580002 (169001)

**5** AIR FEED PIPE  
5580006 (169005)

**6** SPRING  
5580031 (169029)

**18** CYLINDER INNER SLEEVE  
5580017 (169016)

**19** CYLINDER OUTER SLEEVE  
5580018 (169017)

**20** CYLINDER SEAL (2)  
5580015 (169014)

**21** CYLINDER BUFFER RING  
5580016 (169015)

**22** VALVE RING  
5580013 (169011)

**23** KICK PORT PLUG (2)  
5580012 (169010)

**24** KEY (3)  
5580019 (169018)

**29** CHUCK HOUSING  
5580021 (169022)

**30** LATCH RETAINER  
5580024 (162003 WA34)

**31** LATCH BUSHING  
5550007 (REPLACES 162016+162017)

**32** RETAINING PIN  
5580027 (203037)

**33** RETAINER PLUNGER  
5580025 (163015)